

# Raritan®

A brand of  legrand®

## Cascading Guide

---

Release 3.3.10

Copyright © 2017 Raritan, Inc.

USBcascade-1B-v3.3.10-E

March 2017

255-80-0012-00 RoHS

## Safety Guidelines

**WARNING!** Read and understand all sections in this guide before installing or operating this product.

**WARNING!** Connect this product to an AC power source whose voltage is within the range specified on the product's nameplate. Operating this product outside the nameplate voltage range may result in electric shock, fire, personal injury and death.

**WARNING!** Connect this product to an AC power source that is current limited by a suitably rated fuse or circuit breaker in accordance with national and local electrical codes. Operating this product without proper current limiting may result in electric shock, fire, personal injury and death.

**WARNING!** Connect this product to a protective earth ground. Never use a "ground lift adaptor" between the product's plug and the wall receptacle. Failure to connect to a protective earth ground may result in electric shock, fire, personal injury and death.

**WARNING!** This product contains no user serviceable parts. Do not open, alter or disassemble this product. All servicing must be performed by qualified personnel. Disconnect power before servicing this product. Failure to comply with this warning may result in electric shock, personal injury and death.

**WARNING!** Use this product in a dry location. Failure to use this product in a dry location may result in electric shock, personal injury and death.

**WARNING!** Do not rely on this product's receptacle lamps, receptacle relay switches or any other receptacle power on/off indicator to determine whether power is being supplied to a receptacle. Unplug a device connected to this product before performing repair, maintenance or service on the device. Failure to unplug a device before servicing it may result in electric shock, fire, personal injury and death.

**WARNING!** Only use this product to power information technology equipment that has a UL/IEC 60950-1 or equivalent rating. Attempting to power non-rated devices may result in electric shock, fire, personal injury and death.

**WARNING!** Do not use a Raritan product containing outlet relays to power large inductive loads such as motors or compressors. Attempting to power a large inductive load may result in damage to the relay.

**WARNING!** Do not use this product to power critical patient care equipment, fire or smoke alarm systems. Use of this product to power such equipment may result in personal injury and death.

**WARNING!** If this product is a model that requires assembly of its line cord or plug, all such assembly must be performed by a licensed electrician and the line cord or plugs used must be suitably rated based on the product's nameplate ratings and national and local electrical codes. Assembly by unlicensed electricians or failure to use suitably rated line cords or plugs may result in electric shock, fire, personal injury or death.

**WARNING!** This product contains a chemical known to the State of California to cause cancer, birth defects, or other reproductive harm.

## Safety Instructions

1. Installation of this product should only be performed by a person who has knowledge and experience with electric power.
2. Make sure the line cord is disconnected from power before physically mounting or moving the location of this product.
3. This product is designed to be used within an electronic equipment rack. The metal case of this product is electrically bonded to the line cord ground wire. A threaded grounding point on the case may be used as an additional means of protectively grounding this product and the rack.
4. Examine the branch circuit receptacle that will supply electric power to this product. Make sure the receptacle's power lines, neutral and protective earth ground pins are wired correctly and are the correct voltage and phase. Make sure the branch circuit receptacle is protected by a suitably rated fuse or circuit breaker.
5. If the product is a model that contains receptacles that can be switched on/off, electric power may still be present at a receptacle even when it is switched off.

This document contains proprietary information that is protected by copyright. All rights reserved. No part of this document may be photocopied, reproduced, or translated into another language without express prior written consent of Raritan, Inc.

© Copyright 2017 Raritan, Inc. All third-party software and hardware mentioned in this document are registered trademarks or trademarks of and are the property of their respective holders.

#### FCC Information

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential environment may cause harmful interference.

#### VCCI Information (Japan)

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

Raritan is not responsible for damage to this product resulting from accident, disaster, misuse, abuse, non-Raritan modification of the product, or other events outside of Raritan's reasonable control or not arising under normal operating conditions.

If a power cable is included with this product, it must be used exclusively for this product.



**Warning**

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

**CAUTION:**



To reduce the risk of shock — Use indoors only in a dry location. No user serviceable parts inside. Refer servicing to qualified personnel. For use with IT equipment only. Disconnect power before servicing.



SecureLock™

# Contents

Safety Guidelines	ii
Safety Instructions	iii
What's New in the Cascading Guide	ix
<b>Chapter 1 Introduction</b>	<b>1</b>
Hardware Requirements.....	2
Software Requirements .....	2
Overview of the Cascading Modes.....	3
NO Support for Plug-and-Play .....	4
<b>Chapter 2 USB-Cascading Applications</b>	<b>5</b>
Appropriate Applications.....	5
Best Practices .....	7
Inappropriate Applications.....	7
<b>Chapter 3 USB-Cascading Instructions</b>	<b>8</b>
USB-Cascading Restrictions.....	8
Cascading the Raritan devices via USB .....	10
Setting the Cascading Mode.....	12
Port Number Syntax .....	15
Port Forwarding Examples.....	16
Adding, Removing or Swapping Cascaded Devices .....	19
<b>Chapter 4 Network Access</b>	<b>21</b>
Finding the IP Address .....	21
Local Console.....	21
MAC Address.....	22
LCD Display .....	22
HTTP/HTTPS Access .....	26
Supported Web Browsers.....	26
Login to the Web Browser .....	26

SSH/Telnet Access .....	27
SNMP Management.....	28
SNMP Notifications.....	28
Third-Party SNMP Managers .....	28
<b>Chapter 5 Identifying Cascaded Devices</b>	<b>29</b>
Using the Web Interface.....	29
Using the CLI .....	32
Using the SNMP.....	34
Using the LCD Display.....	35
Dot-Matrix LCD Display .....	36
Character LCD Display.....	39
<b>Chapter 6 Updating the Raritan device Firmware</b>	<b>41</b>
<b>Appendix A Connecting the Raritan device to a Computer</b>	<b>42</b>
Making a Connection .....	42
Installing the USB-to-Serial Driver (Optional).....	43
<b>Appendix B Configuring Network Settings</b>	<b>45</b>
Configuration via Web Interface.....	45
Configuration via CLI .....	46
<b>Appendix C Cascading Troubleshooting</b>	<b>52</b>
Possible Root Causes.....	52
Slave Connection and Disconnection Events .....	55
The Ping Tool.....	55
Ping via the Web Interface .....	55
Ping via the CLI .....	56

[Contents](#)

---

<b>Appendix D Wireless LAN Information</b>	<b>58</b>
Supported Wireless LAN Configuration.....	58
USB Wireless LAN Adapters .....	58
<b>Appendix E Extended Cascading with PX3-iX7 Models</b>	<b>60</b>
<b>Appendix F Unsupported Cascading Connections for Port Forwarding</b>	<b>63</b>
<b>Index</b>	<b>67</b>

---

# What's New in the Cascading Guide

Warning: Firmware version 3.3.10 is NOT compatible with old firmware versions in terms of the USB-cascading feature so all devices in a chain must be running version 3.3.10 or later. Otherwise, a networking issue occurs. When upgrading an existing USB-cascading chain from **any version prior to 3.3.10**, the upgrade must start from the last slave device, then the second to last, the third to last, and so on until the master device. Any upgrade without following this sequence results in the networking failure of some cascaded devices.

The following sections have changed or information has been added to the Cascading Guide based on changes and enhancements to the Raritan software, hardware, and/or user documentation.

*Introduction* (on page 1)

*Hardware Requirements* (on page 2)

*Software Requirements* (on page 2)

*Overview of the Cascading Modes* (on page 3)

*NO Support for Plug-and-Play* (on page 4)

*Appropriate Applications* (on page 5)

*USB-Cascading Restrictions* (on page 8)

*Cascading the Raritan devices via USB* (on page 10)

*Setting the Cascading Mode* (on page 12)

*Port Number Syntax* (on page 15)

*Adding, Removing or Swapping Cascaded Devices* (on page 19)

*Dot-Matrix LCD Display* (on page 23)

*Character LCD Display* (on page 25)

*Login to the Web Browser* (on page 26)

*Using the Web Interface* (on page 29)

*Using the CLI* (on page 32)

*Using the SNMP* (on page 34)

*Dot-Matrix LCD Display* (on page 36)

*Character LCD Display* (on page 39)

*Updating the Raritan device Firmware* (on page 41)

*Connecting the Raritan device to a Computer* (on page 42)

*Cascading Troubleshooting* (on page 52)

*Possible Root Causes* (on page 52)

[Chapter 1: What's New in the Cascading Guide](#)

*Slave Connection and Disconnection Events* (on page 55)

*Extended Cascading with PX3-iX7 Models* (on page 60)

*Unsupported Cascading Connections for Port Forwarding* (on page 63)

# Chapter 1 Introduction

Raritan provides a cascading solution, which enables multiple Raritan devices to share the network connectivity by cascading them through the USB or Ethernet interface. The maximum number of devices supported in a cascading configuration is up to 16 devices. For more information, see *Overview of the Cascading Modes* (on page 3).

Each device in the cascading configuration can be accessed and administered over the Internet from anywhere. Therefore, you can access any cascaded device via the Web, SNMP, SSH, Telnet or Modbus interface. Besides, each device can be upgraded respectively.

The first device in the cascading configuration is the master device and the other are slave devices.

This guide focuses on the USB-cascading configurations, which a number of Raritan products support. Ethernet-cascading configurations are only supported by PX3-iX7 power distribution units (PDUs).

---

*Tip: Ethernet cascading with PX3-iX7 PDUs is supported as of release 3.3.10. If you have PX3-iX7 PDUs, you can choose to cascade them via Ethernet ports rather than USB ports so that all slave devices transfer data at a rate of 100Mbps. For details, see **Extended Cascading with PX3-iX7 Models** (on page 60) or refer to the PX3 User Guide.*

---

## In This Chapter

Hardware Requirements.....	2
Software Requirements .....	2
Overview of the Cascading Modes.....	3
NO Support for Plug-and-Play.....	4

---

## Hardware Requirements

The USB-cascading configuration comprises either identical or diverse Raritan products. For example, you can cascade PX2 PDUs only, or you can cascade PX2, PX3, EMX, PX3TS and BCM devices in one USB-cascading configuration.

Below lists the Raritan products supporting the USB-cascading feature.

- PX2 series power distribution units (PDUs)
- PX3 series PDUs, including iX7 models
- EMX asset management devices
- PX3TS transfer switch
- Branch Circuit Monitor 1 (BCM1)
- Branch Circuit Monitor 2 (BCM2), including PMC models

► **[Limitation of a USB-cascading chain connected to the wireless network:](#)**

A Raritan product with two USB-A ports must be the master device, such as PX3 or PX3TS. Slave devices can be any Raritan products shown in the above list. See *Cascading the Raritan devices via USB* (on page 10).

---

## Software Requirements

Firmware version 3.3.10 is NOT compatible with old firmware versions in terms of the USB-cascading feature so all devices in a chain must be running version 3.3.10 or later. Otherwise, a networking issue occurs.

---

*Alternative: You can also choose to have an existing USB-cascading chain keep on running the old firmware without upgrading any device to 3.3.10 or later.*

---

Check firmware versions before cascading Raritan devices and upgrade any device as needed.

---

**Important:** When upgrading an existing USB-cascading chain from any version prior to 3.3.10, the upgrade must start from the last slave device, then the second to last, the third to last, and so on until the master device. Any upgrade without following this sequence results in the networking failure of some cascaded devices. See *Updating the Raritan device Firmware* (on page 41).

---

## Overview of the Cascading Modes

You must apply a cascading mode to the cascading configuration. See [Setting the Cascading Mode](#) (on page 12).

Two cascading modes are available: Bridging and Port Forwarding.

► **Overview:**


- The Bridging mode supports the wired network only, while the Port Forwarding mode supports both wired and wireless networks.
- All cascading modes support a maximum of 16 devices in a chain.
- All cascading modes support both DHCP and static IP addressing.
- In the Bridging mode, each cascaded device has a unique IP address. In the Port Forwarding mode, all cascaded devices share the same IP address.
- Each cascaded device can be remotely accessed through the network regardless of the cascading mode.

► **Illustration:**

In the following diagrams, it is assumed that users enable the DHCP networking in the cascading configuration comprising four devices. "M" is the master device and "S" is the slave device.


• **"Bridging" mode:**

In this mode, the DHCP server communicates with every cascaded device respectively and assigns four *different* IP addresses. Each device has its own IP address. The way to remotely access each cascaded device is completely the same as accessing a standalone device in the network.



- **"Port Forwarding" mode:**

In this mode, the DHCP server communicates with the master device alone and assigns only one IP address. All slave devices share the same IP address as the master device. You must specify a 5XXXX port number (where X is a number) when remotely accessing any slave device via the shared IP address. See *Port Number Syntax* (on page 15).



---

### NO Support for Plug-and-Play

As of release 3.3.10, the USB-cascading configuration no longer supports the plug-and-play function.

For instructions on adding, removing or swapping cascaded devices, see *Adding, Removing or Swapping Cascaded Devices* (on page 19).

# Chapter 2 USB-Cascading Applications

This chapter illustrates several USB-cascading scenarios using PDUs, and points out best practices and the condition the USB-cascading solution should be avoided.

## In This Chapter

Appropriate Applications.....	5
Best Practices .....	7
Inappropriate Applications .....	7

---


## Appropriate Applications

When intending to reduce the number of Ethernet connections or save networking costs, apply the USB-cascading solution.


In the USB-cascading configuration, all Raritan devices are cascaded using USB cables and only the master device (the first one in the chain) is connected to the LAN.

The following illustrate a few USB-cascading scenarios using Zero U PDUs. Red lines in the diagrams represent USB connections.


- ▶ **Scenario 1: Cabinet 1 has four PDUs cascaded, all of which share one Ethernet connection.**



- ▶ Scenario 2: Cabinet 1 and Cabinet 2 have four PDUs respectively. The eight PDUs are cascaded, sharing one Ethernet connection.



- ▶ Scenario 3: Cabinet 1 through Cabinet 4 have two PDUs respectively. The eight PDUs are cascaded, sharing one Ethernet connection.



---

## Best Practices

One Ethernet connection per cabinet is better than one Ethernet connection across cabinets because of the following advantages:

- Easier to manage or maintain one cabinet when all of the cabling and connections are located in the same cabinet.
- Reduces the cross-cabinet cabling.

An eight-device cascaded configuration saves the most Ethernet connections and costs, and it is recommended when:

- Ethernet ports are expensive or limited.
- Available IPv4 addresses are limited.

---

## Inappropriate Applications

Though the USB-cascading solution helps decrease the Ethernet connections and costs, there are two scenarios where this solution is NOT recommended:

► **High network reliability is required:**

The USB-cascading solution increases the number of network bridging points for cascaded devices, which may result in network unreliability. Therefore, when high network reliability is required, establish a separate Ethernet connection for each Raritan device to minimize the number of potential network failure points.

► **High bandwidth is required:**

The USB bandwidth between the master and the first slave device is 12Mbps. Due to this bandwidth limitation, the actual data transfer rate for all slave devices ranges between 8Mbps and 10Mbps. If high bandwidth is required, such as transmission of webcam videos, directly connect that Raritan device to the network to optimize the data transfer rate.

---

*Tip: If you have PX3-iX7 PDUs, you can choose to cascade them via Ethernet ports rather than USB ports so that all slave devices transfer data at a rate of 100Mbps. For details, see **Extended Cascading with PX3-iX7 Models** (on page 60) or refer to the PX3 User Guide.*

---

# Chapter 3 USB-Cascading Instructions

This chapter describes the USB-cascading limitations, instructions and various methods to identify a cascaded Raritan device.

## In This Chapter

USB-Cascading Restrictions.....	8
Cascading the Raritan devices via USB .....	10
Setting the Cascading Mode.....	12
Adding, Removing or Swapping Cascaded Devices .....	19

---

## USB-Cascading Restrictions

Some restrictions apply regardless of whether you are connecting to a wired or wireless network. Other restrictions apply only when connecting to the wireless LAN.

► **General restrictions:**

- All devices in the USB-cascading configuration must run firmware 3.3.10 or later.

---

*Note: To upgrade an existing USB-cascading chain from a version older than 3.3.10, you must start from the last slave device and so on until the master device. Otherwise, a networking issue occurs. For details, see [Updating the Raritan device Firmware](#) (on page 41).*

---

- In the bridging mode, the master device can have "only one" connection to the network. If the master device is a PX3-iX7 PDU with two Ethernet ports, DO NOT connect both ports to the network(s) in this mode.

---

*Note: The port forwarding mode does NOT have such a restriction. In the port forwarding mode, you can enable both wired and wireless networking, or enable both Ethernet ports.*

---

- The cascading mode of all devices in the cascading chain must be the same.
- If the port forwarding mode is chosen, you must make sure both the cascading role and downstream interface are set correctly, or a networking issue occurs.
- All cascading modes support a maximum of 16 devices in a chain.
- The master device must be connected to the LAN. Do NOT connect slave devices to the LAN via a standard network patch cable or a USB wireless LAN adapter.
- Appropriate networking methods vary based on the cascading mode. See **Setting the Cascading Mode** (on page 12).
  - The bridging mode supports the *wired* networking only.
  - The port forwarding mode supports both the *wired* and *wireless* networking.
- Your network switch's port security settings must support the cascading solution. Make sure that packets forwarding is enabled for the external Ethernet port where the master device is connected.

► **Restrictions for the port forwarding mode over "wireless" LAN:**

- You must use the Raritan USB WIFI wireless LAN adapter instead of other WIFI adapters for wireless network connection.
- No external USB hub is used with the master device.
- A Raritan product with two USB-A ports must be the master device, such as PX3 or PX3TS. This is because it requires one USB-A port to connect the USB wireless LAN adapter and the other is to connect a slave device.

---

*Alternative: You can also choose to use a Raritan device with one USB-A port as the master device connected to the wireless network, and all slave devices are connected via Ethernet ports. For example, use the PX2 or EMX as the master, and PX3-iX7 models as slave devices.*

---

## Cascading the Raritan devices via USB


For a list of Raritan products supporting the USB-cascading function, see **Hardware Requirements** (on page 2).

Any certified USB 2.0 cable up to 16 feet (5 meters) long can be used.

Decide the cascading mode first before establishing the chain. All cascading modes support a maximum of 16 devices in a chain.

*Tip: Ethernet cascading with PX3-iX7 PDUs is supported as of release 3.3.10. See **Extended Cascading with PX3-iX7 Models** (on page 60).*

The following illustrates a USB-cascading chain.



Number	Device role
1	Master device
2	Slave 1
3	Slave 2
4	Slave 3

► **To cascade Raritan devices:**

1. Make sure all Raritan devices to be cascaded are running firmware version 3.3.10 or later.

*Note: To upgrade an existing USB-cascading chain from a version older than 3.3.10, you must start from the last slave device and so on until the master device. Otherwise, a networking issue occurs. For details, see **Updating the Raritan device Firmware** (on page 41).*

2. Select one as the master device.
  - When the port forwarding mode over wireless LAN is intended, the master device must be a Raritan product with two USB-A ports, such as PX3, EMX2-888, PX3TS or BCM2.
3. Log in to all devices one by one and select the same cascading mode. See **Setting the Cascading Mode** (on page 12).
  - **Bridging mode:**  
Set the cascading mode of all devices to Bridging.
  - **Port Forwarding mode:**  
Set the cascading mode of all devices to Port Forwarding. Make sure the cascading role and downstream interface are also set correctly.
4. Connect the master device to the LAN, using a method below.
  - Bridging mode: Use a standard network patch cable (CAT5e or higher).
  - Port Forwarding mode: Use a standard network patch cable or a Raritan USB WIFI wireless LAN adapter. For information on the Raritan USB WIFI adapter, see **USB Wireless LAN Adapters** (on page 58). For details on this Raritan WIFI adapter, see **USB Wireless LAN Adapters** (on page 58).
5. Connect the USB-A port of the master device to the USB-B port of an additional Raritan device via a USB cable. This additional device is Slave 1.

6. Connect Slave 1's USB-A port to the USB-B port of an additional Raritan device via another USB cable. The second additional device is Slave 2.
7. Repeat the same step to connect more slave devices.  
You can cascade up to 15 slave devices.

---

## Setting the Cascading Mode

For an overview of different cascading modes, see *Overview of the Cascading Modes* (on page 3).

The cascading mode of all devices in the cascading chain must be the same. If any slave device's cascading mode is different from the master device's, a networking failure occurs on that one and the subsequent slave devices.

Only a user with the Change Network Settings can configure the cascading mode.

► **To configure the cascading mode via the web interface:**

1. Connect the device that you will cascade to the LAN and find its IP address, or connect it to a computer.
  - For the computer connection instructions, see *Connecting the Raritan device to a Computer* (on page 42).
  - To find the IP address, see *Finding the IP Address* (on page 21).
2. Log in to its web interface.
3. Choose Device Settings > Network.
4. Select the preferred mode in the Cascading Mode field.
  - None: No cascading mode is enabled. This is the default.
  - Bridging: Each device in the cascading chain is accessed with a different IP address.
  - Port Forwarding: Each device in the cascading chain is accessed with the same IP address but with a different port number assigned. For details on port numbers, see *Port Number Syntax* (on page 15).

---

*Tip: If selecting Port Forwarding, the Device Information page will show a list of port numbers for all cascaded devices.*

---

5. For the port forwarding mode, one to two more fields have to be configured. Note that if either setting is incorrectly configured, a networking issue occurs.
  - Role: Master or Slave. This is to determine which device is the master and which ones are slave devices.

- Downstream interface: USB or Ethernet (or ETH1/ETH2). This is to determine which port of the master device is connected to Slave 1. Always select USB.
6. Now you can configure the network settings.
    - Bridging mode: Click the BRIDGE section on the same page.
    - Port forwarding mode: Click the ETHERNET (or ETH1/ETH2) or WIRELESS section on the same page, depending on the networking method you prefer.
  7. Click Save.  
For information on accessing each cascaded device in the Port Forwarding mode, see ***Port Forwarding Examples*** (on page 16).
- **To configure the cascading mode via the command line interface (CLI):**
1. Connect the device that you will cascade to the LAN and find its IP address, or connect it to a computer.
  2. Log in to its CLI. To use the SSH or Telnet service, see ***SSH/Telnet Access*** (on page 27).
  3. Type config and press Enter to enter the configuration mode.
  4. Type the following command to set the cascading mode.
- ```
config:#    network <mode> enabled <option1>
```

*Variables:*

- <mode> is one of the following cascading modes.

---

**Important: When enabling either cascading mode, you must make sure the other cascading mode is disabled, or the preferred cascading mode may not be enabled successfully.**

---

| Mode           | Description                                                                                                                        |
|----------------|------------------------------------------------------------------------------------------------------------------------------------|
| bridge         | The network bridging mode, where each cascaded device is assigned a unique IP address.                                             |
| portForwarding | The port forwarding mode, where every cascaded device in the chain shares the same IP address, with diverse port numbers assigned. |

- <option1> is one of the following options:

| Option | Description                              |
|--------|------------------------------------------|
| true   | The selected cascading mode is enabled.  |
| false  | The selected cascading mode is disabled. |

- If Port Forwarding mode is enabled, you must configure two more settings to finish the configuration:

On ALL cascaded devices, you must configure the 'role' setting one by one.

```
config:#    network portForwarding role <option2>
```

On the master device, you must configure the 'downstream interface' setting.

```
config:#    network portForwarding
               masterDownstreamInterface <option3>
```

*Variables:*

- <option2> is one of the following cascading roles:

| Role   | Description                    |
|--------|--------------------------------|
| master | The device is a master device. |
| slave  | The device is a slave device.  |

- <option3> is one of the following options:

| Option                     | Description                                                                       |
|----------------------------|-----------------------------------------------------------------------------------|
| Ethernet (or<br>ETH1/ETH2) | Ethernet (or ETH1/ETH2) port is the port where the 1st slave device is connected. |
| Usb                        | USB port is the port where the 1st slave device is connected.                     |

---

### Port Number Syntax

In the Port Forwarding mode, all devices in the USB-cascading configuration share the same IP address. To access any cascaded device, you must assign an appropriate port number to it.

- Master device: The port number is either *5NNXX* or the standard TCP/UDP port.
- Slave device: The port number is *5NNXX*.

► **5NNXX port number syntax:**

- NN is a two-digit number representing the network protocol as shown below:

| Protocols | NN |
|-----------|----|
| HTTPS     | 00 |
| HTTP      | 01 |
| SSH       | 02 |
| TELNET    | 03 |
| SNMP      | 05 |
| MODBUS    | 06 |

- XX is a two-digit number representing the device position as shown below.

The following table only lists 7 slave devices, but the port forwarding supports up to 15 slave devices.

| Position      | XX |
|---------------|----|
| Master device | 00 |
| Slave 1       | 01 |
| Slave 2       | 02 |
| Slave 3       | 03 |
| Slave 4       | 04 |
| Slave 5       | 05 |
| Slave 6       | 06 |
| Slave 7       | 07 |

For example, to access the Slave 4 device via Modbus/TCP, the port number is 50604. See **Port Forwarding Examples** (on page 16) for further illustrations.

---

*Tip: The full list of each cascaded device's port numbers can be retrieved from the web interface. Choose Maintenance > Device Information > Port Forwarding.*

---

► **Standard TCP/UDP ports:**

The master device can be also accessed through standard TCP/UDP ports as listed in the following table.

| Protocols | Port Numbers |
|-----------|--------------|
| HTTPS     | 443          |
| HTTP      | 80           |
| SSH       | 22           |
| TELNET    | 23           |
| SNMP      | 161          |
| MODBUS    | 502          |

In the Port Forwarding mode, the Raritan device does NOT allow you to modify the standard TCP/UDP port configuration, including HTTP, HTTPS, SSH, Telnet and Modbus/TCP.

---

### Port Forwarding Examples

To access a cascaded device in the Port Forwarding mode, assign a port number to the IP address.

- Master device: Assign proper 5NNXX port numbers or standard TCP/UDP ports. See **Port Number Syntax** (on page 15) for details.
- Slave device: Assign proper 5NNXX port numbers.

**Assumption:** The Port Forwarding mode is applied to a USB-cascading configuration comprising three Raritan devices. The IP address is 192.168.84.77.

► **Master device:**

Position code for the master device is '00' so each port number is 5NN00 as listed below.

| Protocols | Port numbers |
|-----------|--------------|
| HTTPS     | 50000        |

| Protocols | Port numbers |
|-----------|--------------|
| HTTP      | 50100        |
| SSH       | 50200        |
| TELNET    | 50300        |
| SNMP      | 50500        |
| MODBUS    | 50600        |

**Examples using "5NN00" ports:**

- To access the master device via HTTPS, the IP address is:  
*https://192.168.84.77:50000/*
- To access the master device via HTTP, the IP address is:  
*http://192.168.84.77:50100/*
- To access the master device via SSH, the command is:  
*ssh -p 50200 192.168.84.77*

**Examples using standard TCP/UDP ports:**

- To access the master device via HTTPS, the IP address is:  
*https://192.168.84.77:443/*
- To access the master device via HTTP, the IP address is:  
*http://192.168.84.77:80/*
- To access the master device via SSH, the command is:  
*ssh -p 22 192.168.84.77*

► **Slave 1 device:**

Position code for Slave 1 is '01' so each port number is 5NN01 as shown below.

| Protocols | Port numbers |
|-----------|--------------|
| HTTPS     | 50001        |
| HTTP      | 50101        |
| SSH       | 50201        |
| TELNET    | 50301        |
| SNMP      | 50501        |
| MODBUS    | 50601        |

**Examples:**

- To access Slave 1 via HTTPS, the IP address is:  
*https://192.168.84.77:50001/*
- To access Slave 1 via HTTP, the IP address is:  
*http://192.168.84.77:50101/*
- To access Slave 1 via SSH, the command is:  
*ssh -p 50201 192.168.84.77*

► **Slave 2 device:**

Position code for Slave 2 is '02' so each port number is 5NN02 as shown below.

| Protocols | Port numbers |
|-----------|--------------|
| HTTPS     | 50002        |
| HTTP      | 50102        |
| SSH       | 50202        |
| TELNET    | 50302        |
| SNMP      | 50502        |
| MODBUS    | 50602        |

**Examples:**

- To access Slave 2 via HTTPS, the IP address is:  
*https://192.168.84.77:50002/*
- To access Slave 2 via HTTP, the IP address is:  
*http://192.168.84.77:50102/*
- To access Slave 2 via SSH, the command is:  
*ssh -p 50202 192.168.84.77*

---

## Adding, Removing or Swapping Cascaded Devices

Change the cascading mode first before adding any device to a cascading chain, or before disconnecting a cascaded device from the chain.

If you only want to change the cascading mode of an existing chain, or swap the master and slave device, always start from the slave device.

---

*Note: If the following procedures are not followed, a networking issue occurs. When a networking issue occurs, check the cascading connection and/or software settings of all devices in the chain. See [Cascading Troubleshooting](#) (on page 52).*

---

► **To add a device to an existing chain:**

1. Connect the device that you will cascade to the LAN and find its IP address, or connect it to a computer.
2. Log in to this device and set its cascading mode to be the same as the existing chain's cascading mode. See [Setting the Cascading Mode](#) (on page 12).
3. Connect it to the chain, using either USB or Ethernet cable.

► **To remove a device from the chain:**

1. Log in to the desired cascaded device, and change its cascading mode to None.

---

*Exception: If you are going to connect the removed device to another cascading chain, set its cascading mode to be the same as the cascading mode of another chain.*

---

2. Now disconnect it from the cascading chain.

► **To swap the master and slave device:**

- In the bridging mode, you can swap the master and slave devices by simply disconnecting ALL cascading cables from them, and then reconnecting cascading cables. No changes to software settings are required.
- In the port forwarding mode, you must follow the procedure below:
  - a. Access the slave device that will replace the master device, and set its role to 'Master', and correctly set the downstream interface.
  - b. Access the master device, set its role to 'Slave'.
  - c. Swap the master and slave device now. You must disconnect ALL cascading cables connected to the two devices first before swapping them and reconnecting cascading cables.

► **To change the cascading mode applied to a chain:**

1. Access the last slave device, and change its cascading mode.
  - If the new cascading mode is 'Port Forwarding', you must also set its role to 'Slave'.
2. Access the second to last, third to last and so on until the first slave device to change their cascading modes one by one.
3. Access the master device, and change its cascading mode.
  - If the new cascading mode is 'Port Forwarding', you must also set its role to 'Master', and correctly select the downstream interface.

# Chapter 4 Network Access

The master device functions as the network bridge and can transmit IP packets between the LAN and all slave devices connected to it. Therefore, you can remotely access the master and every slave device via the Web, SNMP, SSH, or Telnet interface.

## In This Chapter

|                              |    |
|------------------------------|----|
| Finding the IP Address ..... | 21 |
| HTTP/HTTPS Access .....      | 26 |
| SSH/Telnet Access .....      | 27 |
| SNMP Management.....         | 28 |

---

### Finding the IP Address

There are various ways to retrieve the IP address of a Raritan device.

- Access the local console.
- Use the device's MAC address and common networking tools.
- Operate the front panel LCD display if the Raritan device is a PX3, iX7, PX3TS, BCM or EMX device.

---

#### Local Console

The IP address of the master or slave device is available in each device's local console, which uses the command line interface.

To access the local console, first connect the desired Raritan device to the computer using a serial RS-232 cable, and then use a terminal emulation program on the computer to access it.

You can also access a master device's local console via a USB connection. For details, see the Quick Setup Guide, Online Help or User Guide, which can be downloaded from Raritan website's ***Support page*** (<http://www.raritan.com/support/>).

You can use any terminal emulation programs for local access to the command line interface.

This section illustrates HyperTerminal, which is part of Windows operating systems prior to Windows Vista.

► **To get the IP address using HyperTerminal:**

1. Connect your computer to the Raritan device via a local connection.
2. Launch HyperTerminal on your computer and open a console window. When the window first opens, it is blank.

Make sure the COM port settings use this configuration:

- Bits per second = 115200 (115.2Kbps)
  - Data bits = 8
  - Stop bits = 1
  - Parity = None
  - Flow control = None
3. In the communications program, press Enter to send a carriage return to the Raritan device. Now you should see the Raritan device's IP address displayed in the terminal.

---

### MAC Address

A label is affixed to the Raritan device, showing both the serial number and MAC address.



If necessary, you can find its IP address through the MAC address by using commonly-used network tools. Contact your LAN administrator for assistance.

---

### LCD Display

Some Raritan products have a front panel LCD display which can show the Raritan device's networking information.

Depending on the Raritan product you purchased, the LCD display type varies.

- PX3, iX7, and BCM2 models use a dot-matrix LCD display.
- EMX and BCM1 use a character LCD display.


### Dot-Matrix LCD Display

The dot-matrix LCD display can show both IPv4 and IPv6 networking information.

Note that the diagrams illustrated in this section are for Zero U models, and your dot-matrix LCD display may look slightly different if it is on a 1U or 2U model.


► **To retrieve the IPv4 and/or IPv6 addresses:**

1. If the LCD display is in the Automatic mode, exit it by pressing or . The Main Menu similar to the following is displayed.



2. Press or to select "Device Info" in the Main Menu, and press .
3. Press until IPv4 and/or IPv6 address(es) of the device are displayed.

The diagram illustrates the IP address screen in the 'bridging' mode. For information on the port forwarding mode, see *Dot-Matrix LCD Display* (on page 36).




| Number | Description                                                                                                                                                                                                                                                                           |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ①      | Current cascading mode. <ul style="list-style-type: none"><li>• In the above diagram, it shows the bridging mode.</li></ul>                                                                                                                                                           |
| ②      | IPv4/IPv6 network information, including: <ul style="list-style-type: none"><li>▪ Network configuration: DHCP (or Automatic), or Static. Static represents Static IP.</li><li>▪ The device's IP address.</li><li>▪ IPv4 subnet mask (such as "/24"), or IPv6 prefix length.</li></ul> |

If you do not enable IPv4 or IPv6 settings, a message is displayed to indicate IPv4 or IPv6 is disabled.

### Character LCD Display

The IP address is available in the Device mode, which is indicated by the alphabet 'd' shown at the top of the LCD display. Note that the LCD display only shows the IPv4 address (if available).

Below illustrates the IP address information.



| Section | Example information                                                                                                                                                                                                                                                                                                      |
|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ①       | "d" means the LCD display has entered the Device mode.                                                                                                                                                                                                                                                                   |
| ②       | The LCD display is showing 192, which is one of the four IP address octets. It will cycle through four octets.                                                                                                                                                                                                           |
| ③       | "i4" indicates that the IP address shown on the LCD display is an IPv4 address.                                                                                                                                                                                                                                          |
| ④       | The word "MASTER" indicates the Raritan device is the master device in a cascading configuration. For a slave device, it shows "SLAVE" instead.<br><br><i>Note: As of release 3.3.10, the "MASTER/SLAVE" information is no longer available in the bridging mode, but remains available in the port forwarding mode.</i> |

If you connect your Raritan device to the wireless network, a Wi-Fi icon is displayed at the bottom-right corner.



► **To display the IPv4 address:**

1. Press the MODE button to enter the Device mode, indicated by an alphabet "d" at the top left of the display.
2. The LCD display cycles between the four octets of the IPv4 address, indicated by "i4" at the upper right corner of the display.

For example, 192.168.84.4 cycles in this sequence:

192 --> 168 --> 84 --> 4

---

## HTTP/HTTPS Access

You can remotely access the web interface of any Raritan device in a USB-cascaded configuration by using a web browser. See **Supported Web Browsers** (on page 26) for a list of supported web browsers.

---

### Supported Web Browsers

The following web browsers can be used to access a Raritan device's web interface. For details, see the online help or User Guide for your Raritan device.

- Internet Explorer®
- Windows Edge
- Firefox®
- Safari®
- Google® Chrome®
- Android
- iOS

---

### Login to the Web Browser

You must enable JavaScript in the web browser for proper operation.

► **To log in to the web interface:**


1. Open a browser and type the IP address of the Raritan device.



*Note: The address to access a slave device in the port forwarding mode via non-standard ports is a combination of a protocol (http:// or https://), an IP address and a port number. See **Port Forwarding Examples** (on page 16).*

---

2. If any security alert message appears, accept it.
3. The login screen displays. Type your user name and password. User credentials are case sensitive.



4. [Optional] If a security agreement is displayed, accept it. Otherwise, you cannot log in.
5. Click Login or press Enter. The Raritan device web interface opens.

## SSH/Telnet Access

All devices in the USB-cascading configuration support the SSH or Telnet service.

You can remotely log in to the command line interface (CLI) using an SSH or Telnet client, such as PuTTY.

---

*Note: PuTTY is a free program you can download from the Internet. See PuTTY's documentation for details on configuration.*

---

► **To log in using SSH or Telnet:**

1. Ensure SSH or Telnet has been enabled.
2. Launch an SSH or Telnet client and open a console window. A login prompt appears.

**login as:**

3. Type a name and press Enter. The name is case sensitive.

---

*Note: If using the SSH client, the name must NOT exceed 25 characters. Otherwise, the login fails.*

---

Then you are prompted to enter a password.

```
login as: admin  
admin@192.168.84.88's password: █
```

4. Type a password and press Enter. The password is case sensitive.
5. After properly entering the password, the # or > system prompt appears.

---

*Tip: The "Last Login" information, including the date and time, is also displayed if the same user profile was used to log in to this product's web interface or CLI.*

---

6. You are now logged in to the command line interface and can begin administering the Raritan device.

---

## SNMP Management

In the USB-cascading configuration, the SNMP capability of each Raritan device remains unchanged. A cascaded device is able to send SNMP notifications and communicate with an SNMP manager.

---

### SNMP Notifications

A Raritan device in the USB-cascading configuration can send out SNMP traps or informs to an SNMP destination like a standalone Raritan device. All you have to do is to configure the SNMP notification setting on that device. For details, see "Configuring SNMP Settings" in the online help, which is accessible from the application or on the Raritan website's *Support page* (<http://www.raritan.com/support/>).

---

### Third-Party SNMP Managers

A third-party SNMP manager can communicate with any Raritan device in the USB-cascading configuration. There are no differences made to the SNMP accessibility no matter the device is a master or slave device.

To allow a Raritan device to communicate with an SNMP manager, you must enable the SNMP agent implemented on that device and download the latest SNMP MIB for your SNMP manager. For details, see "Enabling and Configuring SNMP" in the online help, which is accessible from the application or on the Raritan website's *Support page* (<http://www.raritan.com/support/>).

# Chapter 5 Identifying Cascaded Devices

You can retrieve a device's USB-cascading status from one of these interfaces:

- Web interface: Accessible via HTTP or HTTPS.
- Command line interface (CLI): Accessible via SSH, Telnet or the serial interface.
- SNMP: An SNMP manager is required.
- LCD display: Use the front panel LCD display if your Raritan device has it.

Before remotely accessing a Raritan device, you need to get its IP address. See *Finding the IP Address* (on page 21).

## In This Chapter

|                               |    |
|-------------------------------|----|
| Using the Web Interface ..... | 29 |
| Using the CLI .....           | 32 |
| Using the SNMP .....          | 34 |
| Using the LCD Display.....    | 35 |

---

## Using the Web Interface

This section explains how to identify a cascaded device through the web interface.

The following only introduces the web interface of firmware version 3.3.10 or later, which is different from old firmware versions.


1. Log in to the desired Raritan device using a supported web browser. See *HTTP/HTTPS Access* (on page 26).
2. Choose Maintenance > Device Information.
3. Click the Network title bar.



- If the information shown on this page does not match the latest status, press F5 to reload it.

- ▶ **Cascading information in the Bridging mode:**
- The Common section contains two read-only fields for indicating the cascading status. Note that the cascading position is NOT available in the bridging mode.

| Fields          | Description                                                                                    |
|-----------------|------------------------------------------------------------------------------------------------|
| Port Forwarding | Indicates the Port Forwarding is disabled. See <i>Setting the Cascading Mode</i> (on page 12). |
| BRIDGE section  | Indicates the device is in the bridging mode and its IP address.                               |



- ▶ **Cascading information in the Port Forwarding mode:**
- The Common section contains three read-only fields for indicating the cascading status.

| Fields           | Description                                                                                                                                                                                                                                                                         |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Port Forwarding  | Indicates the Port Forwarding is enabled. See <i>Setting the Cascading Mode</i> (on page 12).                                                                                                                                                                                       |
| Cascade Position | Indicates the position of the Raritan device in the cascading configuration. <ul style="list-style-type: none"> <li>▪ 0 (zero) represents the master device.</li> <li>▪ A non-zero number represents a slave device. 1 is Slave 1, 2 is Slave 2, 3 is Slave 3 and so on.</li> </ul> |

| Fields                    | Description                                                                                                                                                                                                                                |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cascaded Device Connected | Indicates whether a slave device is detected on the USB-A or Ethernet port. <ul style="list-style-type: none"> <li>▪ yes: Connection to a slave device is detected.</li> <li>▪ no: NO connection to a slave device is detected.</li> </ul> |

- A master device shows 0(zero) in the Cascade Position field and yes in the Cascaded Device Connected field.

| Common                           |                                                               |
|----------------------------------|---------------------------------------------------------------|
| DNS Servers                      | 192.168.80.249, 192.168.80.19                                 |
| DNS Suffixes                     | rgp.raritan.com.                                              |
| DNS Resolver Preference          | IPv6 Address                                                  |
| IPv4 Routes                      | 192.168.84.0/24 dev ETH1<br>default via 192.168.84.254 (ETH1) |
| IPv6 Routes                      | none                                                          |
| Port Forwarding                  | enabled                                                       |
| <b>Cascade Position</b>          | <b>0 (Master)</b>                                             |
| <b>Cascaded Device Connected</b> | <b>yes</b>                                                    |

- A slave device in the middle position shows a non-zero number which indicates its exact position in the Cascade Position field and yes in the Cascaded Device Connected field.

The following diagram shows 1, indicating it is the first slave - Slave 1.

| Common                           |                               |
|----------------------------------|-------------------------------|
| DNS Servers                      | 192.168.80.249, 192.168.80.19 |
| DNS Suffixes                     | rgp.raritan.com.              |
| DNS Resolver Preference          | IPv6 Address                  |
| Port Forwarding                  | enabled                       |
| <b>Cascade Position</b>          | <b>1 (Slave)</b>              |
| <b>Cascaded Device Connected</b> | <b>yes</b>                    |

- The final slave device shows a non-zero number which indicates its position in the Cascade Position field and *no* in the Cascaded Device Connected field.

The following diagram shows 2, indicating it is the second slave - Slave 2. The Cascaded Device Connected field shows *no*, indicating that it is the final one in the chain.

| Network                   |                               |
|---------------------------|-------------------------------|
| Common                    |                               |
| DNS Servers               | 192.168.80.249, 192.168.80.19 |
| DNS Suffixes              | rgp.raritan.com.              |
| DNS Resolver Preference   | IPv6 Address                  |
| Port Forwarding           | enabled                       |
| Cascade Position          | 2 (Slave)                     |
| Cascaded Device Connected | no                            |

- For a list of port numbers required for accessing each cascaded device in the port forwarding mode, click the Port Forwarding title bar on the same page.



---

## Using the CLI

This section explains how to identify a cascaded device through CLI.

The following only introduces the CLI commands of firmware version 3.3.10 or later, which are different from old firmware versions.

- Log in to the CLI of the desired cascaded device. To use the SSH or Telnet service, see ***SSH/Telnet Access*** (on page 27).
- Type the following CLI commands and press Enter.

```
#       show network
```

► **Information indicating the Bridging mode:**

In the bridging mode, IP-related information is shown under the 'BRIDGE' interface, similar to the following.

```
Interface 'BRIDGE'
  Link
    MAC address:      00:0d:5d:0e:e1:2d
  IPv4
    Config method:   DHCP
    Address:         None
    Preferred hostname: Not configured
    DHCP server:     Not available
  IPv6
    Disabled
```

► **Information indicating the Port Forwarding mode:**

In the Port Forwarding mode, the Port Forwarding status shows 'Enabled'.

```
Port forwarding
  Status:          Enabled
```

The 'Role' or 'Slave number' field indicates the device's position.

- For a master device, the Role field shows 'Master'.

```
Port forwarding
  Status:          Enabled
  Role:            Master
```

- For a slave device, the Role field shows 'Slave'. The 'Slave number' field indicates its position: 1 is the first slave device, 2 is the second, and so on.

```
Port forwarding
  Status:          Enabled
  Role:            Slave
  Slave number:    1
```

## Using the SNMP

Later firmware versions retrieve more USB-cascading information via SNMP than earlier ones. See **Software Requirements** (on page 2) for information on different firmware versions.

The *unitConfigurationTable* in MIB contains entries for USB-cascading information. One SNMP MIB manager, such as a MIB browser, is required for the following operation.

► **When your firmware supports two cascading modes:**

1. Launch your SNMP MIB manager and connect to the desired Raritan device.
2. To find whether the Raritan device is in a USB-cascading configuration, retrieve the value of either one below:
  - SNMP name - **pduDaisychainMemberType**
  - SNMP object identifier (OID) - **1.3.6.1.4.1.13742.6.3.2.2.1.41**

One of the values in the following table is returned.

| SNMP value     | Description                                                                              |
|----------------|------------------------------------------------------------------------------------------|
| standalone (0) | The Raritan device is not in the USB-cascading configuration. It is a standalone device. |
| master (1)     | The Raritan device is the master device.                                                 |
| slave (2)      | The Raritan device is a slave device.                                                    |

3. To check the cascading mode applied, retrieve the value of either one below:
  - SNMP name - **deviceCascadeType**
  - SNMP OID - **1.3.6.1.4.1.13742.6.3.2.2.1.70**

One of the values in the following table is returned.

| SNMP value | Cascading mode       |
|------------|----------------------|
| 0          | Bridging mode        |
| 1          | Port forwarding mode |

4. To identify the device's position in the USB-cascading configuration, retrieve the value of either one below:
  - SNMP name - **deviceCascadePosition**
  - SNMP OID - **1.3.6.1.4.1.13742.6.3.2.2.1.71**

One of the values in the following table is returned.

| SNMP value | Device position     |
|------------|---------------------|
| 0          | Master device       |
| 1 to 15    | Slave 1 to Slave 15 |

5. To find whether the Raritan device is the final slave device, retrieve the value of either one below:

- SNMP name - **cascadedDeviceConnected**
- SNMP OID - **1.3.6.1.4.1.13742.6.3.2.2.1.58**

Check which value is returned. A final slave device has NO slave device connected to its USB-A port.

| SNMP value | Description                                                            |
|------------|------------------------------------------------------------------------|
| true (1)   | A slave device has been connected to this Raritan device's USB-A port. |
| false (2)  | No slave device is connected to this Raritan device's USB-A port.      |

## Using the LCD Display

Some Raritan products have a front panel LCD display which can show USB-cascading information, such as the device position.

Depending on the Raritan product you purchased, the LCD display type varies.

- PX3, iX7, and BCM2 models use a dot-matrix LCD display.
- EMX and BCM1 use a character LCD display.


---

### Dot-Matrix LCD Display


On the dot-matrix LCD display, available cascading information depends on the cascading mode.

Note that the diagrams illustrated in this section are for Zero U models, and your dot-matrix LCD display may look slightly different if it is on a 1U or 2U model.

1. If the LCD display is in the Automatic mode, exit it by pressing




The Main Menu similar to the following is displayed.



2. Press  or  to select "Device Info" in the Main Menu, and press .
3. Press  until the Network Cascading page displays.

► **Bridging mode:**

In the bridging mode, the LCD display only indicates the bridging mode is enabled. The device position information is NOT available.





| Number | Description                                                                                                                                                                                                                                                                               |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ①      | Current cascading mode. <ul style="list-style-type: none"> <li>• In the above diagram, it shows the bridging mode.</li> </ul>                                                                                                                                                             |
| ②      | IPv4/IPv6 network information, including: <ul style="list-style-type: none"> <li>▪ Network configuration: DHCP (or Automatic), or Static. Static represents Static IP.</li> <li>▪ The device's IP address.</li> <li>▪ IPv4 subnet mask (such as "/24"), or IPv6 prefix length.</li> </ul> |

If you do not enable IPv4 or IPv6 settings, a message is displayed to indicate IPv4 or IPv6 is disabled.

► **Port Forwarding mode:**

In the port forwarding mode, the LCD display indicates the cascading mode, device position and the presence/absence of a connected slave device.




| Number | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ①      | Cascading mode-related information, including: <ul style="list-style-type: none"><li>▪ Port Forwarding mode</li><li>▪ Master or Slave</li><li>▪ Cascade position -- This information is available on slave devices only.<br/>1 represents the first slave, 2 represents the second slave, and the like.</li><li>▪ Slave Connected: yes indicates a downstream slave device is detected, and no indicates no downstream slave devices are detected.</li></ul> |
| ②      | The master device's IPv4/IPv6 address.                                                                                                                                                                                                                                                                                                                                                                                                                       |

## Character LCD Display

Note: As of release 3.3.10, the following cascading information is no longer available in the bridging mode, but remains available in the port forwarding mode.

A cascaded device's position is available by operating the LCD display.

Below illustrates a slave device's position.



| Section | Example information                                                                                                                    |
|---------|----------------------------------------------------------------------------------------------------------------------------------------|
| ①       | "d" means the LCD display has entered the Device mode.                                                                                 |
| ②       | "CA" indicates that the cascading information is being displayed.                                                                      |
| ③       | "SLAVE" indicates that this Raritan device is a slave device.<br><i>Note: For a master device, it shows the word "MASTER" instead.</i> |
| ④       | The number 1 means the device position is Slave 1.                                                                                     |

► **To retrieve the device's USB-cascading position information:**

1. Press the MODE button to enter the Device mode, indicated by a 'd' in at the top left of the display.
2. Press the FUNC button until "CA" is displayed at the top right of the display.
3. The device's position is represented by any number defined below:

| Number | Device position |
|--------|-----------------|
| 0      | Master device   |
| 1      | Slave 1         |

| Number | Device position |
|--------|-----------------|
| 2      | Slave 2         |
| 3      | Slave 3         |
| 4      | Slave 4         |
| 5      | Slave 5         |
| 6      | Slave 6         |
| 7      | Slave 7         |

As of release 3.3.10, the port forwarding mode supports up to 15 slave devices so the numbers 8 to 15 may be shown in this mode.

# Chapter 6 Updating the Raritan device Firmware

You can upgrade each individual Raritan device in the USB-cascading configuration through the web interface. The upgrade procedure is completely identical to the procedure for a standalone Raritan device.

Firmware version 3.3.10 is NOT compatible with old firmware versions in terms of the USB-cascading feature so all devices in a chain must be running version 3.3.10 or later. Otherwise, a networking issue occurs.

When upgrading an existing USB-cascading chain from **any version prior to 3.3.10**, the upgrade must start from the last slave device, then the second to last, the third to last, and so on until the master device. Any upgrade without following this sequence results in the networking failure of some cascaded devices.

Firmware files are available on Raritan website's **Support page** (<http://www.raritan.com/support/>).

## ► To update the firmware:

1. Choose Maintenance > Update Firmware.

**Browse...**

2. Click **Browse...** to select an appropriate firmware file.
3. Click Upload. A progress bar appears to indicate the upload process.
4. Once complete, information of both installed and uploaded firmware versions as well as compatibility and signature-checking results are displayed.
  - If anything is incorrect, click Discard Upload.
5. To proceed with the update, click Update Firmware.

*Warning: Do NOT power off the Raritan device during the update.*

6. When the update is complete, the Raritan device resets, and the Login page reappears.

**Important: If you are using the Raritan device with an SNMP manager, download its MIB again after the firmware update to ensure your SNMP manager has the correct MIB for the latest release you are using.**

# Appendix A Connecting the Raritan device to a Computer

To change the cascading mode of any Raritan device, you can connect it to the computer via one of the following ports.

- USB-B port (male)
- ETHERNET port (female)
- RS-232 serial port (model dependent -- male DB9 or female RJ-45 connector)

To use the command line interface (CLI) for configuration, establish an RS-232 or USB connection.

To use a web browser for configuration, make a network connection to the computer. The Raritan device is automatically configured with the following link-local addressing in any network without DHCP available:

- <https://169.254.x.x> (where x is a number)
- <https://pdu.local>

## In This Chapter

|                                                      |    |
|------------------------------------------------------|----|
| Making a Connection .....                            | 42 |
| Installing the USB-to-Serial Driver (Optional) ..... | 43 |

---

## Making a Connection

Establish one of the following connections to a computer.

► **Serial connection for "DB9" RS-232 connector on Raritan device:**

1. Connect one end of the null-modem DB9 cable to the male "DB9" RS-232 port labeled CONSOLE / MODEM on the Raritan device.
2. Connect the other end to your computer's RS-232 port (COM).

► **Serial connection for "RJ-45" RS-232 connector on PX3-iX7:**

- The iX7™ PDU's serial connection procedure is the same as above except that a third party RJ-45 to "DB9 female" adapter/cable is required, such as the blue Cisco adapter cable. This is because the CONSOLE / MODEM port on iX7™ is a female RJ-45 connector.

► **USB connection:**

1. A USB-to-serial driver is required in Windows®. Install this driver before connecting the USB cable. See *Installing the USB-to-Serial Driver (Optional)* (on page 43).

2. Connect a USB cable between the Raritan device's USB-B port and a computer's USB-A port.

► **Direct network connection:**

The Ethernet port must be enabled for this connection to work properly. Per default, the Ethernet port is enabled.

1. Connect one end of a standard network patch cable to the ETHERNET port of the Raritan device.
  - For iX7™, either Ethernet port is fine.
2. Connect the other end to a computer's Ethernet port.
3. On the connected computer, launch a web browser to access the Raritan device, using either link-local addressing: *pdu.local* or *169.254.x.x*.

## Installing the USB-to-Serial Driver (Optional)

The Raritan device can emulate a USB-to-serial converter over a USB connection. A USB-to-serial driver named "Dominion PX2 Serial Console" is required for Microsoft® Windows® operating systems.

Download the Windows driver for USB serial console from the Raritan website's ***Support page*** (<http://www.raritan.com/support/>). The downloaded driver's name is *dominion-serial-setup-<n>.exe*, where <n> represents the file's version number.

There are two ways to install this driver: automatic and manual installation. Automatic driver installation is highly recommended.

► **Automatic driver installation in Windows®:**

1. Make sure the Raritan device is NOT connected to the computer via a USB cable.
2. Run *dominion-serial-setup-<n>.exe* on the computer and follow online instructions to install the driver.

*Note: If any Windows security warning appears, accept it to continue the installation.*

3. Connect the Raritan device to the computer via a USB cable. The driver is automatically installed.

► **Manual driver installation in Windows®:**

1. Make sure the Raritan device has been connected to the computer via a USB cable.
2. The computer detects the new device and the "Found New Hardware Wizard" dialog appears.

- If this dialog does not appear, choose Control Panel > System > Hardware > Device Manager, right-click the *Dominion PX2 Serial Console*, and choose Update Driver.
- 3. Select the option of driver installation from a specific location, and then specify the location where both *dominion-serial.inf* and *dominion-serial.cat* are stored.

---

*Note: If any Windows security warning appears, accept it to continue the installation.*

---

- 4. Wait until the installation is complete.

---

*Note: If the Raritan device enters the disaster recovery mode when the USB serial driver is not installed yet, it may be shown as a 'GPS camera' in the Device Manager on the computer connected to it.*

---

► **In Linux:**

No additional drivers are required, but you must provide the name of the tty device, which can be found in the output of the "dmesg" after connecting the Raritan device to the computer. Usually the tty device is "/dev/ttyACM#" or "/dev/ttyUSB#", where # is an integer number.

For example, if you are using the kermit terminal program, and the tty device is "/dev/ttyACM0," perform the following commands:

```
> set line /dev/ttyACM0  
> Connect
```

# Appendix B Configuring Network Settings

Network settings can be configured through either the web interface or command line interface (CLI). This appendix only shows basic operation. For details, see the online help or User Guide for your Raritan device.

If the bridging mode is intended, you must configure the network settings of each cascaded device respectively.

If the port forwarding mode is intended, you only need to configure the master device's network settings.

## In This Chapter

|                                      |    |
|--------------------------------------|----|
| Configuration via Web Interface..... | 45 |
| Configuration via CLI .....          | 46 |

---

## Configuration via Web Interface

When you are able to connect to the master or slave device over Internet, you can access its web interface to change the network settings.


► **To change initial network settings:**

1. Launch a web browser and type the IP address of the Raritan device in the address bar.



2. Accept any warnings that may appear and log in to that Raritan device using the administrator account.
  - User name: *admin*

- Password: *raritan* (or a new password if you have changed the default)



3. If this is the first time to log in to the Raritan device, you are prompted to change the password. Type the new password.
4. Choose Device Settings > Network.
5. Select an appropriate cascading mode: Bridging or Port forwarding.
  - For the port forwarding mode, you must also set the role and downstream interface correctly.
6. Go to the correct interface to enable IPv4, IPv6 or both protocols.
  - In the bridging mode, click the Bridge interface.
  - In the port forwarding mode, click Ethernet (or ETH1/ETH2) and/or Wireless interface.
7. Depending on which IP protocol has been enabled in the above step, configure the corresponding IP settings.

---

## Configuration via CLI

If you want to configure a master or slave device's network settings via CLI, you must connect that device to a computer via a serial RS-232 connection.

You can also access the master device's CLI through a USB connection. For details, see the Quick Setup Guide, Online Help or User Guide, which can be downloaded from Raritan website's ***Support page*** (<http://www.raritan.com/support/>).

► **To configure network settings via CLI:**

1. On the computer connected to the Raritan device, open a communications program such as HyperTerminal or PuTTY.
2. Select the appropriate COM port, and set the following port settings:

- Bits per second = 115200 (115.2Kbps)
  - Data bits = 8
  - Stop bits = 1
  - Parity = None
  - Flow control = None
- 

*Tip: For a USB connection, you can determine the COM port by choosing Control Panel > System > Hardware > Device Manager, and locating the "Dominion PX2 Serial Console" under the Ports group.*

3. In the communications program, press Enter to send a carriage return to the Raritan device.
4. The Raritan device prompts you to log in. Both user name and password are case sensitive.
  - a. Username: admin
  - b. Password: raritan (or a new password if you have changed it).
5. If prompted to change the default password, change or ignore it.
  - To change it, follow onscreen instructions to type your new password.
  - To ignore it, simply press Enter.
6. The # prompt appears.
7. Type config and press Enter.
8. To configure network settings, type appropriate commands and press Enter. Refer to the following commands list. CLI commands are case sensitive.
9. After finishing the network settings, type apply to save changes. To abort, type cancel.

► **Commands for wired networking:**

*The <ipvX> variable in the following commands is either ipv4 or ipv6, depending on the type of IP protocol you are configuring.*

For all Raritan products other than PX3-iX7, replace the variable <ETH> with the word "ethernet". For PX3-iX7, replace the variable <ETH> with either 'ETH1' or 'ETH2', depending on which Ethernet port you are configuring.

- General IP settings:

| To set or enable                      | Use this command                                                                                             |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------|
| IPv4 or IPv6 protocol                 | network <ipvX> interface <ETH> enabled <option><br><br><option> = <i>true</i> , or <i>false</i>              |
| IPv4 configuration method             | network ipv4 interface <ETH> configMethod <mode><br><br><mode> = <i>dhcp</i> (default) or <i>static</i>      |
| IPv6 configuration method             | network ipv6 interface <ETH> configMethod <mode><br><br><mode> = <i>automatic</i> (default) or <i>static</i> |
| Preferred host name (optional)        | network <ipvX> interface <ETH> preferredHostName <name><br><br><name> = preferred host name                  |
| IP address returned by the DNS server | network dns resolverPreference <resolver><br><br><resolver> = <i>preferV4</i> or <i>preferV6</i>             |

- Static IP configuration:

| To set                      | Use this command                                                                                                                                                      |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Static IPv4 or IPv6 address | network <ipvX> interface <ETH> address <ip address><br><br><ip address> = static IP address, with a syntax similar to the example below.<br>▪ Example: 192.168.7.9/24 |

| To set                            | Use this command                                                                |
|-----------------------------------|---------------------------------------------------------------------------------|
| Static IPv4 or IPv6 gateway       | network <ipvX> gateway <ip address><br><ip address> = gateway's IP address      |
| IPv4 or IPv6 primary DNS server   | network dns firstServer <ip address><br><ip address> = DNS server's IP address  |
| IPv4 or IPv6 secondary DNS server | network dns secondServer <ip address><br><ip address> = DNS server's IP address |
| IPv4 or IPv6 third DNS server     | network dns thirdServer <ip address><br><ip address> = DNS server's IP address  |

► **Commands for wireless networking:**

- General wireless settings:

| To set or enable   | Use this command                                                               |
|--------------------|--------------------------------------------------------------------------------|
| Wireless interface | network wireless enabled <option><br><option> = <i>true</i> , or <i>false</i>  |
| SSID               | network wireless SSID <ssid><br><ssid> = SSID string                           |
| BSSID              | network wireless BSSID <bssid><br><bssid> = AP MAC address or <i>none</i>      |
| 802.11n protocol   | network wireless enableHT <option><br><option> = <i>true</i> , or <i>false</i> |

Appendix B: Configuring Network Settings

| To set or enable         | Use this command                                                                                                                                                                                      |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Authentication method    | <code>network wireless authMethod &lt;method&gt;</code><br><br><code>&lt;method&gt; = psk or eap</code>                                                                                               |
| PSK                      | <code>network wireless PSK &lt;psk&gt;</code><br><br><code>&lt;psk&gt; = PSK string</code>                                                                                                            |
| EAP outer authentication | <code>network wireless eapOuterAuthentication &lt;outer_auth&gt;</code><br><br><code>&lt;outer_auth&gt; = PEAP</code>                                                                                 |
| EAP inner authentication | <code>network wireless eapInnerAuthentication &lt;inner_auth&gt;</code><br><br><code>&lt;inner_auth&gt; = MSCHAPv2</code>                                                                             |
| EAP identity             | <code>network wireless eapIdentity &lt;identity&gt;</code><br><br><code>&lt;identity&gt; = your user name for EAP authentication</code>                                                               |
| EAP password             | <code>network wireless eapPassword</code><br><br>When prompted to enter the password for EAP authentication, type the password.                                                                       |
| EAP CA certificate       | <code>network wireless eapCACertificate</code><br><br>When prompted to enter the CA certificate, open the certificate with a text editor, copy and paste the content into the communications program. |

The content to be copied from the CA certificate does NOT include the first line containing "BEGIN CERTIFICATE" and the final line containing "END CERTIFICATE." If a certificate is installed, configure the following:

| Whether to                                                             | Use this command                                                                                            |
|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Verify the certificate                                                 | network wireless enableCertVerification <option1><br><br><option1> = <i>true</i> or <i>false</i>            |
| Accept an expired or not valid certificate                             | network wireless allowOffTimeRangeCerts <option2><br><br><option2> = <i>true</i> or <i>false</i>            |
| Make the connection successful by ignoring the "incorrect" system time | network wireless allowConnectionWithIncorrectClock <option3><br><br><option3> = <i>true</i> or <i>false</i> |

- **Wireless IPv4 / IPv6 settings:**

Commands for wireless IP settings are identical to those for wired networking. Just replace the variable <ETH> with the word 'wireless'. The following illustrates a few examples.

| To set or enable          | Use this command                                                                                                |
|---------------------------|-----------------------------------------------------------------------------------------------------------------|
| IPv4 configuration method | network ipv4 interface WIRELESS configMethod <mode><br><br><mode> = <i>dhcp</i> (default) or <i>static</i>      |
| IPv6 configuration method | network ipv6 interface WIRELESS configMethod <mode><br><br><mode> = <i>automatic</i> (default) or <i>static</i> |

- ▶ **To verify network settings:**

After exiting the above configuration mode and the # prompt reappears, type this command to verify all network settings.

- show network

# Appendix C Cascading Troubleshooting

Any accessibility problem occurred on one of the devices in the cascading chain may result in failure to access all downstream slave devices that are connected to it.

## In This Chapter

|                                                 |    |
|-------------------------------------------------|----|
| Possible Root Causes.....                       | 52 |
| Slave Connection and Disconnection Events ..... | 55 |
| The Ping Tool.....                              | 55 |

---

### Possible Root Causes

The following lists the network accessibility issues and possible root causes.

You can always troubleshoot the software settings by connecting the Raritan device to a computer if network access to that Raritan device fails. See *Connecting the Raritan device to a Computer* (on page 42).

| Symptom                             | Probable cause                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Failure to access the master device | <ul style="list-style-type: none"> <li>• Network connection to the master device is lost.</li> <li>• No power is supplied to the master device.</li> <li>• The Ethernet or wireless interface on the master device is disabled.</li> <li>• IPv4 (or IPv6) settings are disabled on the master device.</li> <li>• In the port forwarding mode, the master device's role is incorrectly set to 'Slave'.</li> <li>• In the port forwarding mode, the interface where the network is connected is incorrectly selected as the downstream interface.</li> <li>• For the wireless networking, one of the following may lead to the accessibility failure: <ul style="list-style-type: none"> <li>▪ The USB wireless LAN adapter attached to the master device is not the Raritan USB WIFI LAN adapter. See <b>USB Wireless LAN Adapters</b> (on page 58).</li> <li>▪ The wireless LAN configuration is not supported. See <b>Supported Wireless LAN Configuration</b> (on page 58).</li> <li>▪ The installed CA certificate chain contains any certificate that has expired or is not valid yet.</li> </ul> </li> </ul> |

| Symptom                          | Probable cause                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Failure to access a slave device | <ul style="list-style-type: none"> <li>• Network connection to the master device is lost.</li> <li>• The cascading cable connected to the slave device in question or any upstream device (if available) is loose or lost.</li> <li>• No power is supplied to the slave device in question or any upstream devices.</li> <li>• The Ethernet or wireless interface on the master device is disabled.</li> <li>• IPv4 (or IPv6) settings are disabled on the slave device in question.</li> <li>• The cascading mode of the slave device in question or any upstream device is set incorrectly. For example, the master device is set to Bridging, but one of the slave devices is set to Port Forwarding.</li> <li>• In the port forwarding mode, the master device's role is incorrectly set to 'Slave'.</li> <li>• In the port forwarding mode, the master device's downstream interface is incorrectly set. For example, you use a USB cable to connect the 1st slave device, but select the Ethernet port as the downstream interface.</li> <li>• In the port forwarding mode, the role of the slave device in question or any upstream device is set to 'Master' instead of 'Slave'.</li> <li>• In the port forwarding mode, the port number you added to the IP address is incorrect. See <b>Port Number Syntax</b> (on page 15).</li> <li>• The firmware version of the slave device in question or any upstream device is older than 3.3.10.</li> </ul> |

*Tip: To determine which Raritan device may be the failure point of network, you may ping each Raritan device in the cascading chain, or check the slave-related events in the event log of each Raritan device. See **Slave Connection and Disconnection Events** (on page 55).*

► **For a PX3-iX7 cascading chain, also check the following:**

- Whether the Ethernet interface (ETH1 or ETH2) where the network or cascading cable is connected is disabled on the slave device in question or any upstream device.
- Whether the connection complies with the cascading guidelines if it is set to the port forwarding mode. See **Unsupported Cascading Connections for Port Forwarding** (on page 63).

---

## Slave Connection and Disconnection Events

In the bridging mode, events regarding connection/disconnection of a downstream slave device via USB is NOT logged.

However, in the port forwarding mode, whenever the connection or disconnection of a downstream slave device via USB is detected, the Raritan device at the USB-A end of the USB cable logs it in the internal log. Note that the Raritan device at the USB-B end of the cable does NOT log these events.

There are two slave-related events:

| Event              | Description                                                                                                 |
|--------------------|-------------------------------------------------------------------------------------------------------------|
| Slave connected    | This log entry is generated when a Raritan device detects the presence of a slave device on its USB-A port. |
| Slave disconnected | This log entry is generated when it detects the disconnection of a slave device from its USB-A port.        |

---

## The Ping Tool

The Raritan device provides a ping tool in the web interface and CLI so you can ping any host or Raritan device in your data center.

---

### Ping via the Web Interface

To log in to the web interface, see [HTTP/HTTPS Access](#) (on page 26).

The Ping tool is useful for checking whether a host is accessible through the network or Internet.

► **To ping a host:**

1. Choose Maintenance > Network Diagnostics.
2. Type values in the following fields.

| Field              | Description                                                                           |
|--------------------|---------------------------------------------------------------------------------------|
| Network Host       | The name or IP address of the host that you want to check.                            |
| Number of Requests | A number up to 20.<br>This determines how many packets are sent for pinging the host. |

3. Click Run Ping to ping the host. The Ping results are then displayed.

---

### Ping via the CLI

You can access the CLI interface by connecting a computer to the Raritan device or using SSH/Telnet. See **SSH/Telnet Access** (on page 27) for details.

You must perform the ping command in the diagnostic mode. To enter the diagnostic mode, type the following command and press Enter.

```
# diag
```

After the diag> or diag# prompt appears, you can perform the ping command.

This ping command sends the ICMP ECHO\_REQUEST message to a network host for checking its network connectivity. If the output shows the host is responding properly, the network connectivity is good. If not, either the host is shut down or it is not being properly connected to the network.

```
diag> ping <host>
```

*Variables:*

- <host> is the host name or IP address whose networking connectivity you want to check.

*Options:*

- You can include any or all of additional options listed below in the ping command.

| Options           | Description                                                                                                    |
|-------------------|----------------------------------------------------------------------------------------------------------------|
| count <number1>   | Determines the number of messages to be sent. <number1> is an integer number between 1 and 100.                |
| size <number2>    | Determines the packet size. <number2> is an integer number in bytes between 1 and 65468.                       |
| timeout <number3> | Determines the waiting period before timeout. <number3> is an integer number in seconds ranging from 1 to 600. |

The command looks like the following when it includes all options:

## Appendix C: Cascading Troubleshooting

```
diag>      ping <host> count <number1> size <number2> timeout <number3>
```

# Appendix D Wireless LAN Information

The USB-cascading configuration supports either a wired or wireless LAN when in the port forwarding mode. See *Setting the Cascading Mode* (on page 12).

This appendix provides information regarding wireless LAN configuration and LAN adapters.

## In This Chapter

|                                           |    |
|-------------------------------------------|----|
| Supported Wireless LAN Configuration..... | 58 |
| USB Wireless LAN Adapters .....           | 58 |

---

### Supported Wireless LAN Configuration

If wireless networking is preferred, ensure that the wireless LAN configuration of your Raritan device matches the access point. The following is the wireless LAN configuration that the Raritan device supports.

- Network type: 802.11 A/B/G/N
- Protocol: WPA2 (RSN)
- Key management: WPA-PSK, or WPA-EAP with PEAP and MSCHAPv2 authentication
- Encryption: CCMP (AES)

---

**Important:** Supported 802.11 network protocols vary according to the wireless LAN adapter being used with the Raritan device. See *USB Wireless LAN Adapters* (on page 58).

---

---

### USB Wireless LAN Adapters

A standalone Raritan device supports the use of all USB wireless LAN adapters below. However, the port forwarding mode only supports the use of the Raritan USB WIFI LAN adapter.

| Wi-Fi LAN adapters  | Supported 802.11 protocols |
|---------------------|----------------------------|
| SparkLAN WUBR-508N  | A/B/G/N                    |
| Proxim Orinoco 8494 | A/B/G                      |
| Zyxel NWD271N       | B/G                        |
| Edimax EW-7722UnD   | A/B/G/N                    |

| Wi-Fi LAN adapters    | Supported 802.11 protocols |
|-----------------------|----------------------------|
| TP-Link TL-WDN3200 v1 | A/B/G/N                    |
| Raritan USB WIFI      | A/B/G/N                    |

*Note: To use the Edimax EW-7722UnD or Raritan USB WIFI wireless LAN adapter to connect to an 802.11n wireless network, the handshake timeout setting must be changed to 500 or greater, or the wireless connection will fail.*

---

## Appendix E Extended Cascading with PX3-iX7 Models

Only PX3-iX7 PDUs support cascading via either Ethernet or USB ports. These PDUs support cascading via Ethernet ports because they have two Ethernet ports. Other Raritan products do NOT support Ethernet cascading.

There is no restriction of using which Ethernet port of PX3-iX7 for network connection and which port for cascading, but the 'green' ETH1 port (ETH①10/100/1000) is highly recommended for network connection because it supports up to 1000 Mbps.

An Ethernet-cascaded device must have its Ethernet interface enabled for the networking to work properly. By default the Ethernet interface is enabled.

The distance between two Ethernet-cascaded PDUs can be up to 100 meters, but the distance between two USB-cascaded PDUs supports up to 5 meters only.

Decide the cascading mode first before establishing the chain. All cascading modes support a maximum of 16 devices in a chain.

When establishing a cascading chain in the port forwarding mode, make sure you follow the guidelines described in the section titled *Unsupported Cascading Connections for Port Forwarding* (on page 63).


---

**Special application:** You can "loop" a cascading chain to create network communication redundancy (bridging mode only), but only when your network supports R/STP protocol. Make sure that your network has R/STP enabled if using a cascade loop (bridging mode) or else network loops may occur.

---

If wanted, you can mix Ethernet and USB cascading in a PX3-iX7 cascading chain. The following diagram illustrates such a chain.

For instructions on USB cascading, see *Cascading the Raritan device via USB* (see "Cascading the Raritan devices via USB" on page 10).



| Number | Device role   |
|--------|---------------|
| 1      | Master device |
| 2      | Slave 1       |

| Number | Device role |
|--------|-------------|
| ③      | Slave 2     |
| ④      | Slave 3     |

► **To cascade iX7™ PDUs via Ethernet ports:**

1. Make sure all Raritan devices to be cascaded are running firmware version 3.3.10 or later.
2. Choose one iX7™ PDU as the master device.
3. Log in to all devices one by one and select the same cascading mode. See *Setting the Cascading Mode* (on page 12).
  - **Bridging mode:**  
Set the cascading mode of all devices to Bridging.
  - **Port Forwarding mode:**  
Set the cascading mode of all devices to Port Forwarding. Make sure the cascading role and downstream interface are also set correctly.
4. Connect the master device to the LAN, using a method below.
  - Bridging mode: Use a standard network patch cable (CAT5e or higher).
  - Port Forwarding mode: Use a standard network patch cable or a Raritan USB WIFI wireless LAN adapter. For information on the Raritan USB WIFI adapter, see *USB Wireless LAN Adapters* (on page 58).
5. Connect the available Ethernet port of the master device to either Ethernet port of another iX7™ via a standard network patch cable. This additional iX7™ device is Slave 1.
6. Connect Slave 1's available Ethernet port to either Ethernet port of another iX7™ via a standard network patch cable. The second additional device is Slave 2.
7. Repeat the same step to connect more iX7™ devices.
8. Configure or change the network settings of the master and/or slave devices as needed.
  - Bridging: Each cascaded device has its own network settings. For example, some devices can have DHCP-assigned IP and the others can have static IP addresses.
  - Port forwarding: Only the master device's network settings should be configured.

## Appendix F Unsupported Cascading Connections for Port Forwarding


The following guidelines must be obeyed for establishing a cascading chain in the **port forwarding** mode.

- Each cascaded device, except for the master device, must have only one upstream device.
- Each cascaded device, except for the last slave device, must have only one downstream device.
- Use only one cable to cascade two devices. That is, NO simultaneous connection of USB and Ethernet cables between two cascaded devices.

The following diagrams illustrate cascading connections that are NOT supported.


► **UNSUPPORTED connections:**

- One cascaded device has two upstream devices via Ethernet cables.




## Appendix F: Unsupported Cascading Connections for Port Forwarding

- One cascaded device has two upstream devices via Ethernet and USB cables.




- One cascaded device has two downstream devices.



## Appendix F: Unsupported Cascading Connections for Port Forwarding

- One device is connected to another device via two cascading cables - USB and Ethernet cables.



# Index

## A

Adding, Removing or Swapping Cascaded Devices • ix, 4, 19  
Appropriate Applications • ix, 5

## B

Best Practices • 7

## C

Cascading the Raritan devices via USB • ix, 2, 10, 61  
Cascading Troubleshooting • ix, 19, 52  
Character LCD Display • ix, 25, 39  
Configuration via CLI • 46  
Configuration via Web Interface • 45  
Configuring Network Settings • 45  
Connecting the Raritan device to a Computer • ix, 12, 42, 52

## D

Dot-Matrix LCD Display • ix, 23, 24, 36

## E

Extended Cascading with PX3-iX7 Models • x, 1, 7, 10, 60

## F

Finding the IP Address • 12, 21, 29

## H

Hardware Requirements • ix, 2, 10  
HTTP/HTTPS Access • 26, 29, 55

## I

Identifying Cascaded Devices • 29  
Inappropriate Applications • 7  
Installing the USB-to-Serial Driver (Optional) • 42, 43  
Introduction • ix, 1

## L

LCD Display • 22  
Local Console • 21  
Login to the Web Browser • ix, 26

## M

MAC Address • 22  
Making a Connection • 42

## N

Network Access • 21  
NO Support for Plug-and-Play • ix, 4

## O

Overview of the Cascading Modes • ix, 1, 3, 12

## P

Ping via the CLI • 56  
Ping via the Web Interface • 55  
Port Forwarding Examples • 13, 16, 26  
Port Number Syntax • ix, 4, 12, 15, 16, 54  
Possible Root Causes • ix, 52

## S

Safety Guidelines • ii  
Safety Instructions • iii  
Setting the Cascading Mode • ix, 3, 9, 11, 12, 19, 30, 58, 62  
Slave Connection and Disconnection Events • x, 54, 55  
SNMP Management • 28  
SNMP Notifications • 28  
Software Requirements • ix, 2, 34  
SSH/Telnet Access • 13, 27, 32, 56  
Supported Web Browsers • 26  
Supported Wireless LAN Configuration • 53, 58

## T

The Ping Tool • 55  
Third-Party SNMP Managers • 28

## U

Unsupported Cascading Connections for Port  
Forwarding • x, 54, 60, 63  
Updating the Raritan device Firmware • ix, 2, 8,  
11, 41  
USB Wireless LAN Adapters • 11, 53, 58, 62  
USB-Cascading Applications • 5  
USB-Cascading Instructions • 8  
USB-Cascading Restrictions • ix, 8  
Using the CLI • ix, 32  
Using the LCD Display • 35  
Using the SNMP • ix, 34  
Using the Web Interface • ix, 29

## W

What's New in the Cascading Guide • ix  
Wireless LAN Information • 58